



Save time and expenses when changing oil.



OIL FILTER CONVERSION KIT FOR OLD TYPES OF ZETOR TRACTORS AND ENGINES.

Set contains:

Full flow filter body, filter element, pipe, **reduction valve for full flow filter**, connecting and sealing material.

Assembly Instructions:

When installing oil filter conversion kit, the enclosed reduction valve located in the pan of the engine on the oil pump must be exchanged. The filter body must be fitted with a centering tube and an o-ring. Loosely attach to the block and tighten the full flow filter bolts of the delivery line. Then tighten the filter housing fixing screws and check for leaks.